



DIY Installation Guide

Reversible Latch Lock

- NO loose parts
- NO need to open lock
- NO tools needed to reverse the lock.

Just pull & turn.




In meeting South African standards SANS 4:2008 a durability test of a 100 000 cycles, was conducted without jamming or breaking.




Gelmar

Fitting Instructions


1. Use the lock body as a template to mark off the position of the cut out in the face of the door.




2. Drill a row of 18mm deep in the center of the marked out area.




3. Using a chisel, clean out the mortice area between the marked lines.




4. Slide the lock into the chiseled hole and draw a line around the faceplate.




5. Recess the area inside the lines to a depth of 2mm.



6. Hold lock against the side of the door in line with the recess and mark off the key and spindle holes.




7. Drill through the door a 22mm diameter spindle hole, and a 10mm key hole.




8. If required, pull and turn the latch to match hand of door.



9. Insert lock into the door. Insert spindle and key. Screw the lock into the door.



10. Screw furniture onto door and turn key. Close door and mark the position of the latch and deadbolt on the door frame.



11. Hold striker plate against frame and mark off the latch and deadbolt areas. Drill a row of Ø12mm holes and clean out this area. Fit striker plate.

