






1 Door Pocket Door System






Pocket Door Fittings



Technical Diagrams



Tools required



* When the 3rd slide is used, door height is able to increase to 1.5m.




Installation

STEP 1

Installing the hinges onto the door

1. Attach the provided hinges onto the pre-bored doors using 16mm chipboard screws.


*The boring hole should be $\varnothing 35\text{mm}$ offset from the side edge by 9mm (hole center 26.5mm from the side edge) and 80mm from the top edge.



STEP 3

Installing the runners in the carcass


1. Centralise the follow strip in the height of the carcass.
2. The 1st hole position on the runner must be 46mm from the front of the carcass.



STEP 5

Installing the support roller

1. Drill a $\varnothing 8\text{mm}$ hole 10mm deep in the base and top of the carcass.
*The hole center must be 41mm in from the side and $9.5\text{mm} + \text{door thickness}$ from the front of the carcass.
2. Screw the wood insert into the drilled hole, using a 5mm allen key.
3. Secure the roller into the wood insert.




STEP 2

Attach the runners to the follow strip

1. Attach the supplied runners to the top and bottom of each follow strip using chipboard screws.

The follow strip must sit flush against the lip on the mounting brackets


*The follow strip must be a 12mm thick board, 80mm wide.



STEP 4

Installing the hinges on the follow strip

1. Mount the hinge mounting plates onto the follow strip.
The front hole position must be recessed 37mm from the front of the follow strip. The mounting plate must be centralised to the width of the runner.



STEP 6

Installing the striker plate

1. Find the centre point of the top of the carcass, using your tape measure.
2. Position the striker plate 16mm back from the front of the carcass and mark the screw hole positions.
3. Secure the striker plate in place using 16mm chipboard screws.

